



Unpacking Instructions

GENERAC[®] 9.5 CHIPPER W/SHREDDER

Tools and Supplies Needed:

- Utility Knife
- Wire Cutters
- Hammer
- Pry Bar
- Gloves
- Safety Glasses

CAUTION

- The Straps and Cable Ties may be under tension. Wear Safety Glasses when cutting the Straps and Cable Ties to protect your eyes.
- Wear Safety Glasses and Gloves when removing the wood strap to protect your eyes from flying debris and your hands from sharp staples and wood splinters.

Unpack (Box 1 of 2)

1. Cut the Tape on the top flaps of the Box with the Utility Knife and open the Box.
2. Remove the Product Package (large plastic bag containing user manuals etc.) from the Box.
3. The Power Unit is secured to the wood base. Cut the two vertical box corners near the Leg end of the Power Unit and lay the box side down to gain access to the blocking.
4. Cut the two big zip ties holding the axle to the wood base using the Wire Cutters.
5. Pry off the wood strap that is stapled across the top of the Leg using the Pry Bar and Hammer. You do not need to remove the remaining wood blocks.
6. Tilt/lift the Leg out of the wood block area and roll the Power Unit off the wood base.

Unpack (Box 2 of 2)

1. Cut the Tape on the top flaps of the Box with the Utility Knife and open the Box.
2. Remove the Shredder Guard & Bracket Assembly and the Chipper Guard & Bracket Assembly that are on top.
3. Lift out the cardboard support and then lift out the large Shredder Hopper.
4. Lift out the Chipper Chute enclosed in cardboard and remove the Chute from the cardboard.
5. Remove the rubber Discharge Guard and the folded Debris Bag that are tucked in the cardboard.

Continue with the “Assembling the 9.5 Chipper w/Shredder” section in Chapter 2 of your Generac Chipper w/Shredder Operator’s Manual to continue with the assembly of the machine.

If there are any questions contact us at 1-888-545-6576. Do not discard the shipping materials until you are fully satisfied with your new 9.5 Chipper w/Shredder.