



Leaf Catcher

Accessory for the
NEUTON Garden Cart

Attaching the Leaf Catcher

These instructions explain how to attach and remove the Leaf Catcher. If you have any questions, please call Customer Service at 1-866-NEUTON1 (638-8661) for assistance.

Unpack the parts for the Leaf Catcher, and remove every plastic bag.

To attach the Leaf Catcher

1. Insert the four rod holders into the four side stake holes on your Garden Cart. Be sure to face the rod holder clip outwards (as shown in Figure 1). Push the rod holders all the way in until they snap into place.
2. Insert two rods into the front-facing holes on the front rod holders; insert two rods into the rear-facing holes on the rear rod holders (see Figure 2).



Figure 1. Insert the rod holders



Figure 3. Slide on the fabric channels

3. Place the Leaf Catcher's black panel into your Cart with the seams showing, aligning its shape to the cart. Push the button on the cinch strings clips and slide the clips most of the way out; this gives you some working room when you attach the Leaf Catcher to the rods.
4. Locate a fabric channel on the corner of the Leaf Catcher, then slide the channel completely over the rod on that corner (Figure 3 shows how the channel looks after it is completely on a rod). Do the same for the other three fabric channels.
5. Push the top of the rods into the slot on the Leaf Catcher's banding (as shown in Figure 4). Do this for all four rods.
6. Cinch the strings to tighten the Leaf Catcher.



Figure 2. Insert the rods that hold the Leaf Catcher



Figure 4. Push the rods into the banding slots

To remove the Leaf Catcher

Before removing a filled Leaf Catcher, cinch down the ends to secure the contents.

The easiest way to remove the Leaf Catcher is to simply remove the four rods. Detach the rods from the receiving folds at the top of the Leaf Catcher, then remove the rods from the cart. Put the rods safely aside, perhaps even in your Cart.



COUNTRY HOME PRODUCTS[®], Inc.

MEIGS ROAD, P.O. BOX 25, VERGENNES, VERMONT 05491

1-866-NEUTON1 (638-8661) • www.neutonowners.com

NEUTON[®] and the NEUTON logo are trademarks of Country Home Products, Inc. All rights reserved.

208491 A ©2005 CHP, Inc.